Handleiding - Engels

Manual - Correct execution of a rinse

- 1. Preparation
- 1.1. Disconnecting the hose: At the end of filling, disconnect the hose from the tank and connect it to the rinse water tank.
- 1.2. Blowing out the machine:
- Start the blow-out cycle via SCADA.
- Check if the pipe is completely empty.
- If not, start the blow-out cycle again.
- 2. Cleaning the filter
- 2.1. Remove the filter from the filter housing and clean it with water.
- 2.2. Place the filter back and tighten the screws securely.
- 3. Removing residual product
- 3.1. Open the steel tap and the valve to remove residual product from the machine.
- 3.2. Do not forget to close the valves after draining.
- 4. Starting the rinse cycle
- 4.1. On the SCADA interface, press 'rinse' and the cycle will start automatically.
- 5. Inspection & completion
- 5.1. Observe the water outflow during rinsing and check if it is clear.
- 5.2. In the future, a refractometer will automatically indicate when rinsing is complete.